

DAVISCOMMS (S) PTE LTD

Blk 70 Ubi Crescent, #01-07, Ubi Techpark, Singapore 408570
Tel: 65-65471127 Fax: 65-65471129

PAGER SERIAL NUMBER DETERMINATION CHART EFFECTIVE For ALL PAGERS SHIPPED AFTER MAY 8, 2002

PRODUCT CODE = First three (3) characters of the serial number when the product is shipped.

<u>PAGER MODEL</u>	<u>PRODUCT CODE</u>
Bravo 500 Flex	50F
Bravo 500 Pocsag	50P
Bravo 501 Flex	51F
Bravo 501 Pocsag	51P
Talkabout 500 Flex	T0F
Talkabout 500 Pocsag	T0P
Talkabout 501 Flex	T1F
Talkabout 501 Pocsag	T1P
Bravo 600 Flex	60F
Scriptor Flex	S0F
Bravo 700 Pocsag	70P
Advisor Pocsag	A0P
Bravo 800 Flex	80F
Bravo 800 Pocsag	80P
TMR1F	R1F
TMR1P	R1P
Bravo 800 Programming Cradle	80C
Bravo 501 / Br502 Programming Cradle	51C
BR501PLUS Flex	5PF
BR502 Flex	52F
BR502 C Flex	52C
BR502 Pocsag	52P
BR802 Flex	82F
BR802 Pocsag	82P
Q31 (FinalStep)	WT1
Bravo 800 E Pocsag	8EP
Bravo 800 L Pocsag	8LP
TMR1F+	R2F
TrafficGauge Singapore	TGS
BR802 L Flex	2LF
BR802 L Pocsag	2LP
BR802 A/AL Flex	82A
BR802 B/BL Flex	82B
BR802 C Pocsag	82C
BR802 D/DL Flex	82D
USB Programmer	USB
BR802 E Pocsag	82E
BR802 G Pocsag	82G
BR802 H/HL Flex	82H
MTD 1000 MTD	

FOURTH CHARACTER DESIGNATOR:

“D” = Shipments up to March 2006

With effect from shipments in April 2006,
The fourth character designates the type of PLL used:

- “A” = NOVA Receiver**
- “B” = NPC Receiver**
- “C” = ALL CRYSTAL Receiver**
- “E” = Narrowband Receiver**
- “X” = Not used**

FIFTH CHARACTER DESIGNATOR:

The fifth character designates the year the product was shipped from the manufacturing facility but cannot be vowels “I” and “O”:

“A” = 2000, “B” = 2001, “C” = 2002, “D” = 2003, “E” = 2004, “F” = 2005, “G” = 2006, “H” = 2007, “J” = 2008, “K” = 2009, “L” = 2010

SIXTH CHARACTER DESIGNATOR:

The sixth character designates the month the product was shipped from the manufacturing facility:

“A or B” = January, “C or D” = February, “E or F” = March, “G or H” = April, “J or K” = May, “L or M” = June, “N or P” = July, “Q or R” = August, “S or T” = September, “U or V” = October, “W or X” = November and “Y or Z” = December

SEVENTH through TENTH CHARACTER DESIGNATOR:

The last four (4) characters of the serial number are sequential numbers but CANNOT contain “Y”, “0”, “1”, or any vowels (“A”, “E”, “I”, “O”, “U”).

Serial Number Example: 51PACJ8888

Bravo 501 Pocsag (Product Code “51P”) with NOVA receiver (PLL code “A”), Factory Ship Year is 2002 (Year Code “C”), Factory Ship Month is first half month of May (Month Code “J”), unit sequence code (8888).